




**Additional Information**

Product type	small table
Laptop compatibility	17 inches
Color	cream
Others	adjustable height 24-32 cm adjustable tilt up to 30° silicone stoppers for laptop, mouse
Size	52 x 30 x 1.2 cm



**1. Installation and uninstallation operations**


Fold the table legs in the direction of the arrows to install the small table



Fold the table legs in the direction of the arrows to fold the small table


**2. Adjusting the height of the small table**

Pull up



Pull up to the desired height and it will lock automatically


Press




Press the button and push the top board

Press the easy unlock button, then push the top board to the desired height, it will lock automatically

**3. Using the silent button to adjust the tilt of the top board**




Simultaneously press the buttons on both sides of the table (those indicated in the image) to adjust the tilt of the top board



Tilt the top board continuously between 0 and 36 degrees

Adjust the tilt to the desired position and release the buttons



Install the laptop stopper in the indicated position

**4. Installation of the laptop stopper**

You will find the stopper in the product box. It is installed by pressing in the place shown in the image. Install it before adjusting the tilt of the table with the laptop on it.

**Package contents:** notebook table, user instructions

**Precautions**

Keep the product away from moisture. Do not expose the product to rain or humid air. Keep the product away from liquids.

Keep the product away from fire and heat sources. Do not bring the product close to fire or other heat sources (stoves, radiators, etc.)